


Programming Limit Settings for the First Time


Somfy® RTS Motors

If you did not request Talius to pre-set the limit settings on your unit prior to shipping, follow the steps below to set UPPER and LOWER Limits for the first time. If you requested Talius to pre-set the limits but need to adjust them, please refer to the instructions on the reverse.

INITIATE PROGRAMMING MODE


- 1** On the remote, press both the **UP** and **DOWN** buttons at the same time until the motor jogs.
- Note: After every command the motor will jog to confirm.*
- 

CHECK THE DIRECTION OF OPERATION


- 2** Press and hold the **DOWN** button on the remote and confirm that the motor moves in the down direction (the motor will operate in momentary fashion). To change the direction, press and hold the **MY (stop)** button until the motor jogs.
- 

- 3** Operate motor to your desired Upper Limit position.


SET THE LOWER LIMIT

- 4** Press and hold the **MY (stop)** and **DOWN** buttons on the remote until the motor moves in the down direction, then release.
- Stop the motor where the Lower Limit should be set. Adjust by pressing the **UP** or **DOWN** buttons on the remote.
- 

SET THE UPPER LIMIT

- 5** Press and hold the **MY (stop)** and **UP** button on the remote to move the motor to the desired Upper Limit position, then release.
- The motor will stop at the original upper point. Adjust if necessary.
- 

CONFIRM THE LIMIT SETTINGS

- 6** Press and hold the **MY (stop)** button until the motor jogs to confirm the setting.
- 

SAVE THE LIMIT SETTINGS

- 7** Press and hold the **PROGRAM** button on the back of the remote until the motor jogs. It will now operate in a maintained fashion.
- Double check limits as a precaution.



Programming Button

Adjusting the Pre-set Limit Settings

Somfy® RTS Motors

Follow the steps below if you need to adjust the factory pre-set upper or lower limit settings. If you did not request pre-set settings for your unit, please follow the instructions on the reverse to set the limits for the first time.

During the following steps the motor will operate in a maintained fashion, therefore, you only need to press the **UP** or **DOWN** buttons on the remote momentarily to move the motor, and the **MY (Stop)** button must be pressed in order to stop it at its desired limit.

❶ ADJUST THE **UPPER** LIMIT

1. Move the motor to its preset **UPPER** limit position and let it stop
2. Press the **UP** and **DOWN** buttons simultaneously on the remote until the motor jogs, then release
3. Adjust to a **NEW UPPER** limit position
4. Press the **MY/STOP** button until the motor jogs, then release.
5. Check it

❷ ADJUST THE **LOWER** LIMIT

1. Move the motor to its preset **LOWER** limit position and let it stop
2. Press the **UP** and **DOWN** buttons simultaneously on the remote until the motor jogs, then release
3. Adjust to a new **LOWER** limit position
4. Press the **MY/STOP** button until the motor jogs, then release.
5. Check it

TO ADD A REMOTE/CHANNEL OR SUN AND WIND SENSOR:

First press the programming button on the back of the already programmed remote until the motor jogs. Then press the programming button on the new remote or sun/wind sensor that you would like to add, until the motor jogs.



TO RESET THE MOTOR:

You will need to disconnect power (120vac) for 2 seconds, reconnect for 8 seconds, disconnect or another 2 seconds and reconnect. The motor should start to move and then stop on its own (if this does not happen, continue to perform the disconnects until it does). Once the motor stops moving on its own, press and hold the programming button on the back of the remote and count to ten without letting go until the motor jogs twice.

For Limit Setting example watch: <https://youtu.be/fmyRXkBj8MA>

